



NE><US

*NEW*

for design, electronic, packaging,





NEXUS

The Nexus remote control is the new product for the specialist in the duplication of residential radio remote controls.

It is new in design, in packaging, in electronics.

Available with 2 and 4 channels in 2 models:

Nexus F to duplicate the fixed code in frequency 433.92 MHz;

Nexus M to duplicate fixed codes in frequency 280-868 MHz e the rolling codes in frequency 433 and 868 MHz

---

First check of a code in Nexus M: if you press a button the green light appears it is certain that there is a fixed code in the relevant channel; if when you press a button a red light appears it is certain that it is in the relevant channel there is a rolling code, the brand of which can be verified with the new Radar diagnostic.



NEXUS

## Nexus F:

duplication procedure:

1. press and hold buttons 1 and 2 (3 in 4 channels) until the blue LED remains steady after 10 flashes;
  2. release both keys;
  3. transfer the code of the original remote control placing it side by side with the Nexus F until the blue LED of the Nexus F flashes quickly;
  4. press the desired channel button to confirm.
- The blue LED turns off to signify that the Nexus F has learned the original code

➤ Video Tutorial for Nexus F: <https://youtu.be/jtGi-aH5jF8>



NEXUS

## Nexus M:

- duplication procedure for simple fixed and rolling codes:
- press and hold buttons 1 and 2 (3 in 4 channels) until the green LEDs flash 6 times and change to red;
- transfer the original code; the red LED remains steady for 2 seconds and switches to intermittent flashing;
- re-pass the original code for confirmation and when the LED turns green
- press the desired channel button to confirm. The green LED remains steady and then turns off once duplication has taken place.
- For simple rolling codes, proceed with the association to the receiver using the I.D.A. automatic procedure. (Intelligent Direct Activation): press and hold the button in which you duplicated the code; the red LEDs light up steadily and release when the red LEDs start flashing until they turn off completely





NE<US

## Nexus M:

- duplication procedure with **Nexus M** for **Faac**, **Bft** complex codes:
- press and hold buttons **1** and **2** (**3** in **4** channels) until the green LEDs flash **6** times and change to red;
- transfer the original code; the red LEDs remain steady for **2** seconds and then flash intermittently;
- activate the emission of the source code of the original remote control and transfer it to the **Nexus** which will emit a green light confirming the duplication.
- Press the desired channel button and **Nexus M** will glow red.
  
- **Faac SLH** is a direct code, **Bft** is a code that must be associated with the receiver with the **I.D.A** procedure.
  
- In the case of copying the copy, the source code is output from the **Nexus M** by simultaneously pressing keys **1** and **2** (**1** and **3** in **4** channels) for one second and pressing the key in which the original code is stored



NE<US

# VIDEO TUTORIAL

---

- **Nexus F** for fixed code 433,932 MHz:
  - <https://youtu.be/jtGi-aH5jF8>
- **Nexus M** for Faac SLH Master rolling code:
  - <https://youtu.be/en8gaLG0QRY>



NE<US

## Lista compatibilità e procedura inserimento in ricevente

in RX: agire in ricevente  
con I.D.A, Intelligent Direct Activation

### ACM

TX2, TX2 COLOR, TX4 in RX

### ADYX

TE4433H BLUE, 433-HG BRAVO con I.D.A.

### ALLMATIC

BROWN, BROWN RED, BRO.OVER, PASS,  
MINIPASS, TECH3, FOR4 con I.D.A.

### APERIO

GO, GO PRO, GO MINI in RX

### APERTO (Sommer)

4020-TX03-434, TX02-434-2, TX02-868-2 in RX

### APRIMATIC

TR, TM4, TXM con I.D.A.

### AVIDSEN

I0425I, I04250, I04250 OLD, I04250 RED, I04257,  
I04350, 654250, TX4 I I4253 in RX

### BALLAN

FM400, FM400E in RX

### BENINCA

TO. GO. WV, TWV, ROLLKEY, APPLE, LOT WCV, CUPIDO, TO.GO.  
QV, HAPPY VA, TO.GO. VA con I.D.A.

### BENINCA

IO in RX

### BFT

MITTO, MITTO M, MITTO RCB, MITTO A,  
TRC, GHIBLI, MURALE, KLEIO con I.D.A.

### CARDIN

TRQ S449, TRQ S449 GREEN (PRECODE), TXQ S449, TXQ S449  
GREEN, TRQ S486, TXQ S486, S437 TX, XRADO con I.D.A.

### CASALI

GENIUS/CASALI A252RC con I.D.A.

### CHAMBERLAIN/LIFT MASTER/MOTOR

LIFT 953ESTD, 37I LM, 97I LM, 84330E, 94334CE,  
94333E/94334E/94335E, 9747E, IA5639-7, IA5477, IA6487, I32B2372,  
94330EML/9333EML/94335EML, 84330EML/84333EM- in RX

### COMUNELLO

KEEP in RX

### DASPI

ZERO RC in RX

### DEA SYSTEM

PUNTO 278, GOLDR, GENIE R 273, GENIE R-GT2M, MIO TR, GT2M, TRN  
in RX

### DITEC/ENTREMATI

BIXLP, GOL4, BIXLG, ZEN con I.D.A.



# List of what Nexus M can duplicate and code of association procedure to receiver

in RX: agire in ricevente  
con I.D.A, Intellingent Direct Activation

## FAAC

TML 433SLH, DL 868 SLH, XT 868 SLH, XT 433 SLH, T 868 SLH, T 433 SLH, XT 868 SLH BLACK, XT 433 SLH BLACK **codice diretto**

## GENIUS

AMIGO JA332-JA334 868, AMIGOLD 868, KILO 433 JLC, KILO 868 JLC **codice diretto**

## HORMANN 128 bit

HS 868 - Bi Secur **codice diretto**

## KEY

900TXB-42R, TXB 44R, SUB 44R **in RX**

## MHOUSE

TX3, TX4, GTX4 **con I.D.A**

## NOVOFERM

MCHS, MICRO-NOVOTRON 502, MINI-NOVOTRON 504, MICRO-NOVOTRON 502, MICRO-NOVOTRON 504, MICRO-NOVOTRON 31, MICRO-NOVOTRON 51, MINI-NOVOTRON 30, MINI-NOVOTRON 50, MNHS, MINI NOVOTRON 522 **in RX**

## FAAC

XT 433 RC, TE43 3HG, XT4 433 RCBE **con I.D.A.**

## GENIUS

BRAVO, ECHO **con I.D.A.**

## JCM

NEO, TWIN **con I.D.A**

## KING GATES

CLIPPER, STYLO **con I.D.A**

## MOOVO

MT4G **con I.D.A**

## PRASTEL

MTE, MPSTLE, MPSTP2E, TCE, BFOR, TRQ-P, SLIM-E **con I.D.A.**

## FADINI

JUBI-SMALL, JUBI 433, DIVO 71/4 **con I.D.A**

## GIBIDI

AUI 600, AUI 600 WOOD, AUI 680, AUI 680 WOOD, DOMINO, MAKO **con I.D.A.**

## JCM

GO, GO PORTIS, GO NORTON, GO MINI **in RX**

## LIFE

FIDO **in RX**

## NICE

SMILO, FLOR-S, VERY-VR, FLOR-S ERA, ONE (ON), ON ERA, INTI, ERGO, PLANO, ONE (ON FM) **con I.D.A.**

## RIB

LITHIO **in RX**



NE<X>US

in RX: agire in ricevente  
con I.D.A, Intellingent Direct Activation

## List of what Nexus M can duplicate and code of association procedure to receiver

---

### SEA

HEAD 433, HEAD 868, SMART DUAL COPY con I.D.A.

### SOMFY

K-EASY, K-EASY NEW, K-EASY OLD, MITTO, KEY GO RTS, TELIS RTS, KEYTIS RTS, KEYTIS RTS NS, ALARMA in RX

### TAU

250K-SLIMRP, 250K-SLIMR, 250T-4RP con I.D.A.

### VDS

ECO-R, TRQ P con I.D.A.

### SEAV

BE HAPPY RS, BE SMART in RX

### SOMMER

4010, 4011, 4014 TX03-434-2, 4013 TX03-434-4, 4020 TX03-868-4, 4026 TX03-868-2, 4022 TX02-434-2, 4025 TX02-868-2, 4031 TX08-868-4 in RX

### TELCOMA

FM400E, FM400 in RX

### SILVELOX

MHz 2007, QUARZ SAW con I.D.A.

### STAGNOLI

KALLISTO, VENUS AV223 in RX

### V2

TSC, TXC, TRC, HANDY, PHOENIX, PHOX 433, PHOENIX 868, PHOX 868 con I.D.A..